

CUSTOMER SUPPORT

Pliant Technologies offers technical support via phone and email from 07:00 to 19:00 Central Time (UTC-06:00), Monday through Friday.

1.844.475.4268 or +1.334.321.1160
customer.support@plianttechnologies.com

You may also visit our website (www.plianttechnologies.com) for live chat help. (Live chat available 08:00 to 17:00 Central Time (UTC-06:00), Monday through Friday.)

VIDEO TUTORIAL

Scan the QR code below to view an instructional video on the setup of the in-ear headset.



IN THIS BOX

WHAT'S INCLUDED WITH THE IN-EAR HEADSET?

- In-Ear Headset
- Rubber Ear Bud Tips
- Foam Ear Bud Tips
- Generic Silicon Ear Molds (x2) (Left, Right)
- Magnetic Cable Clip
- Nylon Storage Pouch
- Quick Start Guide

ACCESSORIES

OPTIONAL ACCESSORIES

- PAC-PTT-DMG: MicroCom In-Line PTT Adapter with Dual 3.5mm Connectors
- PAC-PTT-TA6F: CrewCom In-Line PTT Adapter with Dual 3.5mm & TA6F Connectors



COPYRIGHT © 2024 Pliant Technologies, LLC. All rights reserved. Pliant®, the Pliant "P" logo, and MicroCom® are registered trademarks of Pliant Technologies, LLC. All other trademarks are property of their respective owners.

Document Reference: D0000707_B

QUICK START GUIDE



This document applies to headset models PHS-IEHU-DMG, PHS-IEHU-4F, and PHS-IEHU-TA6F and to adapter models PAC-PTT-DMG and PAC-PTT-TA6F.

For more information visit
www.plianttechnologies.com

SETUP

1. **Attach generic or custom ear mold to headset.** Make sure it is completely flush with the headset.



Generic Ear Mold
(right or left)



Custom Ear Mold
(not supplied)

2. **Attach rubber or foam ear bud tip.**

Press firmly so it is fully attached.

Note: If you have a custom ear mold, skip this step.



Rubber Ear Bud



Assembled Headset
(Generic Ear Mold)

3. **Make sure the small dot on microphone boom is turned towards your mouth.** If it is not, gently turn the boom until it facing the correct direction.

Note: Do not remove the rubber band on the microphone. It ensures the microphone windscreen stays in place.



4. **Connect headset to a CrewCom Radio Pack or MicroCom BeltPack.** Press firmly until it clicks to make sure the headset connector is seated properly.

Note: When using a Pliant Technologies CrewCom Radio Pack, it is required to manually set the Mic Type to Electret. This setting can be found under User Settings.

PTT BUTTON

For use with PHS-IEHU-DMG only.



PAC-PTT-DMG for use with MicroCom BeltPacks



PAC-PTT-TA6F for use with CrewCom C12 Radio Packs

1. **Use the connector on the left in the images above to connect adapter to the PHS-IEHU-DMG headset.** Press firmly until it clicks to make sure the connector is seated properly.

Note: Headset side must be aligned as shown below for proper function of the PTT adapter.



2. **Use the connector on the right in the images above to connect adapter to a CrewCom C12 Radio Pack or MicroCom BeltPack.** Press firmly until it clicks to make sure the connector is seated properly.
3. **Enable talk on the BeltPack or Radio Pack.** Press and hold the PTT button while talking.